

# EMX-BSWP

Intel® Celeron® Processor N3160  
Mini ITX Motherboard

## User's Manual



4<sup>th</sup> Ed – 29 November 2017

## FCC Statement



THIS DEVICE COMPLIES WITH PART 15 FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS "A" DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES.

THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE WHEN THE EQUIPMENT IS OPERATED IN A COMMERCIAL ENVIRONMENT. THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS.

OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE HARMFUL INTERFERENCE IN WHICH CASE THE USER WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT HIS OWN EXPENSE.

## Notice

This guide is designed for experienced users to setup the system within the shortest time. For detailed information, please always refer to the electronic user's manual.

## Copyright Notice

Copyright © 2017 Avalue Technology Inc., ALL RIGHTS RESERVED.

No part of this document may be reproduced, copied, translated, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the prior written permission of the original manufacturer.

## Trademark Acknowledgement

Brand and product names are trademarks or registered trademarks of their respective owners.

## Disclaimer

Avalue Technology Inc. reserves the right to make changes, without notice, to any product, including circuits and/or software described or contained in this manual in order to improve design and/or performance. Avalue Technology assumes no responsibility or liability for the use of the described product(s), conveys no license or title under any patent, copyright, or masks work rights to these products, and makes no representations or warranties that

these products are free from patent, copyright, or mask work right infringement, unless otherwise specified. Applications that are described in this manual are for illustration purposes only. Avalue Technology Inc. makes no representation or warranty that such application will be suitable for the specified use without further testing or modification.

### Life Support Policy

Avalue Technology's PRODUCTS ARE NOT FOR USE AS CRITICAL COMPONENTS IN LIFE SUPPORT DEVICES OR SYSTEMS WITHOUT THE PRIOR WRITTEN APPROVAL OF Avalue Technology Inc.

As used herein:

1. Life support devices or systems are devices or systems which, (a) are intended for surgical implant into body, or (b) support or sustain life and whose failure to perform, when properly used in accordance with instructions for use provided in the labeling, can be reasonably expected to result in significant injury to the user.
2. A critical component is any component of a life support device or system whose failure to perform can be reasonably expected to cause the failure of the life support device or system, or to affect its safety or effectiveness.

### A Message to the Customer

#### *Avalue Customer Services*

Each and every Avalue's product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new Avalue device is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Avalue has come to be known.

Your satisfaction is our primary concern. Here is a guide to Avalue's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

#### *Technical Support*

We want you to get the maximum performance from your products. So if you run into technical difficulties, we are here to help. For the most frequently asked questions, you can easily find answers in your product documentation. These answers are normally a lot more detailed than the ones we can give over the phone. So please consult the user's manual first.

To receive the latest version of the user's manual; please visit our Web site at:

<http://www.avalue.com.tw/>

### ***Product Warranty***

Avalue warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Avalue, or which have been subject to misuse, abuse, accident or improper installation. Avalue assumes no liability under the terms of this warranty as a consequence of such events. Because of Avalue's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If any of Avalue's products is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time, and freight. Please consult your dealer for more details. If you think you have a defective product, follow these steps:

1. Collect all the information about the problem encountered. (For example, CPU type and speed, Avalue's products model name, hardware & BIOS revision number, other hardware and software used, etc.) Note anything abnormal and list any on-screen messages you get when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information available.
3. If your product is diagnosed as defective, obtain an RMA (return material authorization) number from your dealer. This allows us to process your good return more quickly.
4. Carefully pack the defective product, a complete Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

# Content

<b>1. Getting Started</b>	<b>8</b>
1.1 Safety Precautions	8
1.2 Packing List	8
1.3 Document Amendment History	9
1.4 Manual Objectives	10
1.5 System Specifications	11
1.6 Architecture Overview—Block Diagram	14
<b>2. Hardware Configuration</b>	<b>15</b>
2.1 Product Overview	16
2.2 Jumper and Connector List	17
2.3 Setting Jumpers & Connectors	19
2.3.1 Serial port 1/2/3/4/5/6 pin9 signal select (JRI1/JRI2/JRI3/JRI4/JRI5/JRI6)	19
2.3.2 SATA2/MSATA1 mPCIe slot selector (JMSW1)	19
2.3.3 LVDS Back Light power selection (JSBKL1)	20
2.3.4 AT/ATX Power Mode Select (JSATX1)	20
2.3.5 Clear CMOS (CMOS1)	21
2.3.6 LCD Inverter connector (JBKL1)	21
2.3.7 Serial port 1/2 connector (COM1/2)	22
2.3.8 Serial port 3/4/5/6 connector (COM3/4/5/6)	22
2.3.9 Serial Port 1 RS485/422 Mode connector (JRS485)	23
2.3.10 General purpose I/O connector (DIO1)	23
2.3.11 SATA Power connector 1/2 (SPWR1/2)	24
2.3.12 Power connector (PWR1)	24
2.3.13 USB connector 3/4 (USB3/4)	25
2.3.14 Battery connector (BT1)	25
2.3.15 LVDS connector (LVDS1)	26
2.3.16 Audio connector (FAUD1)	27
2.3.16.1 Signal Description –Front Audio connector (FAUD1)	27
2.3.17 LPC connector (JLPC1)	28
2.3.18 EC_Program (EC1)	28
2.3.19 PS/2 keyboard & mouse connector (KBMS1)	29
2.3.20 SPI connector (SPI1)	29
2.3.21 Sony/Philips Digital Interface (SPDIF1)	30
2.3.22 Speaker connector (SPK1)	30
2.3.23 Miscellaneous setting connector 1 (FPT1)	31
2.3.24 Miscellaneous setting connector 2 (FPT2)	31

## EMX-BSWP User's Manual

2.3.25	LED indicator connector 1 (LED1)	32
2.3.26	LED indicator connector 2 (LED2)	32
2.3.27	CPU fan connector (FAN1)	33
<b>3.BIOS Setup</b>		<b>34</b>
3.1	Introduction	35
3.2	Starting Setup	35
3.3	Using Setup	36
3.4	Getting Help	37
3.5	In Case of Problems	37
3.6	BIOS setup	38
3.6.1	Main Menu	38
3.6.1.1	System Language	39
3.6.1.2	System Date	39
3.6.1.3	System Time	39
3.6.2	Advanced Menu	39
3.6.2.1	Driver Health	40
3.6.2.2	Trusted Computing	41
3.6.2.3	APCI Settings	45
3.6.2.4	IT8528 Super IO Configuration	49
3.6.2.4.1	Serial Port 1 Configuration	50
3.6.2.4.2	Serial Port 2 Configuration	51
3.6.2.4.3	Serial Port 3 Configuration	52
3.6.2.4.4	Serial Port 4 Configuration	53
3.6.2.4.5	Serial Port 5 Configuration	53
3.6.2.4.6	Serial Port 6 Configuration	54
3.6.2.5	H/W Monitor	55
3.6.2.6	S5 RTC Wake Settings	56
3.6.2.7	Serial Port Console Redirection	57
3.6.2.8	CPU Configuration	58
3.6.2.8.1	Socket 0 CPU Information	61
3.6.2.9	SATA Configuration	62
3.6.2.10	Miscellaneous Configuration	65
3.6.2.11	LPSS & SCC Configuration	66
3.6.2.12	Network Stack Configuration	69
3.6.2.13	CSM Configuration	70
3.6.2.14	SDIO Configuration	75
3.6.2.15	USB Configuration	76
3.6.2.16	IntelRMT Configuration	80
3.6.3	Chipset	81
3.6.3.1	North Bridge	82

3.6.3.1.1	Intel IGD Configuration .....	83
3.6.3.1.2	IGD - LCD Control .....	85
3.6.3.2	South Bridge .....	89
3.6.3.2.1	Azalia Configuration .....	89
3.6.3.2.2	USB Configuration .....	91
3.6.3.2.3	PCI Express Configuration .....	93
3.6.4	Security.....	97
3.6.4.1	Secure Boot menu .....	98
3.6.4.1.1	Key Management.....	99
3.6.5	Boot .....	100
3.6.6	Save and exit.....	104
<b>4.</b>	<b>Drivers Installation.....</b>	<b>106</b>
4.1	Install Chipset Driver .....	107
4.2	Install VGA Driver.....	108
4.3	Install USB3.0 Driver .....	109
4.4	Install Serial IO Driver .....	110
4.5	Install SMSC Hub Driver .....	111
4.6	Install Audio Driver (For Realtek ALC662 HD Audio) .....	112
4.7	Install LAN Driver (For Intel I211AT) .....	113
<b>5.</b>	<b>Mechanical Drawing .....</b>	<b>115</b>

# 1. Getting Started

## 1.1 Safety Precautions

### Warning!



Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

### Caution!



Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

## 1.2 Packing List

Before you begin installing your single board, please make sure that the following materials have been shipped:

- 1 x EMX-BSWP motherboard
- 2 x SATA cables
- 1 x I/O Shield
- 1 x SATA Power Cable



If any of the above items is damaged or missing, contact your retailer.

### 1.3 Document Amendment History

Revision	Date	By	Comment
1 <sup>st</sup>	January 2016	Avalue	Initial Release
2 <sup>nd</sup>	April 2016	Avalue	Add System Specifications Note
3 <sup>rd</sup>	August 2017	Avalue	Update System Specifications
4 <sup>th</sup>	November 2017	Avalue	Update System Specifications

### 1.4 Manual Objectives

This manual describes in details Avalue Technology EMX-BSWP Single Board.

We have tried to include as much information as possible but we have not duplicated information that is provided in the standard IBM Technical References, unless it proved to be necessary to aid in the understanding of this board.

We strongly recommend that you study this manual carefully before attempting to set up EMX-BSWP or change the standard configurations. Whilst all the necessary information is available in this manual we would recommend that unless you are confident, you contact your supplier for guidance.

Please be aware that it is possible to create configurations within the CMOS RAM that make booting impossible. If this should happen, clear the CMOS settings, (see the description of the Jumper Settings for details).

If you have any suggestions or find any errors regarding this manual and want to inform us of these, please contact our Customer Service department with the relevant details.

## 1.5 System Specifications

System	
<b>CPU</b>	Intel® Celeron® Processor N3160 (2M Cache, up to 2.24 GHz)
<b>BIOS</b>	AMI uEFI BIOS, 64 Mbit SPI Flash ROM
<b>I/O Chip</b>	EC IT8528E
<b>System Memory</b>	2 x 204-pin DDR3L 1600MHz SODIMMs, up to 8GB
<b>Watchdog Timer</b>	H/W Reset, 1sec. – 65535sec./min.1sec. or 1min. step
<b>H/W Status Monitor</b>	CPU temperature monitoring Voltages monitoring CPU fan speed control
<b>Expansion</b>	1 x full size Mini PCI-e support mSATA (SATA III and mSATA Switchable Through jumper) 1 x full size Mini PCI-e support WiFi module 1 x SIM card slot 1 x PCI-e x1 1 x SD card slot support SD/ SDHC 3.0 Card
<b>Optional Parts</b>	Optional Infineon SLB9665 support TPM 2.0 Optional eMMC 32GB
<b>S3/S4</b>	Yes (S0/S3/S4/S5)
Display	
<b>Resolution</b>	HDMI: 3840 x 2160 @ 30 Hz, 2560 x 1600 @ 60 Hz VGA: 2048 x 1536 @ 60 Hz 2CH 18/24bits LVDS 1920 x 1080 Chrontel. CH7511B eDP to LVDS Converter HDMI +VGA+LVDS Triple Display
Internal I/O Connectors	
<b>External I/O Connector</b>	Storage: - 1 x full size Mini PCI-e support mSATA (SATA III and mSATA Switchable Through jumper) - 2 x SATA power connectors 1 x full size Mini PCI-e support WiFi or communication module 1 x PCI-e x1 1 x SIM card Slot COM: COM1:

## EMX-BSWP User's Manual

	<p>-COM 1 support RS- RS232/422/485 connector, with / +5V &amp; +12V Supported and RS422/485 by BIOS setting</p> <p>1 x 2 x 5 pin, pitch 2.00mm connector for COM1: support RS-232 connector, Pin 9 with / +5V &amp; +12V Supported</p> <p>1 x 2 x 3 pin, pitch 2.00mm connector for COM1: support RS422/485 connector, Pin 5 with / +5V Supported</p> <p>COM2~6:</p> <p>- 5 x 2 x 5 pin, pitch 2.00mm connector for COM2~6: support RS-232 connector, Pin 9 with / +5V &amp; +12V Supported</p> <p>2 x 2 x 5 pin, pitch 2.54mm connector for 4 USB 2.0</p> <p>1 x 2 x 6 pin, pitch 2.00mm connector for GPIO: 8 bits</p> <p>1 x 2 x 4 pin, pitch 2.00mm connector for BIOS SPI</p> <p>1 x 2 x 5 pin, pitch 2.00mm connector for EC SPI</p> <p>1 x 2 x 5 pin, pitch 2.0mm connector for LPC</p> <p>1 x horizontal type battery connector (Battery cable 170mm length)</p> <p>1 x 2 x 5 pin, pitch 2.54mm connector for front panel 1</p> <p>1 x 2 x 5 pin, pitch 2.54mm connector for front panel 2</p> <p>1 x 2 x 20 pin, pitch 1.25mm connector for LVDS (must be using DF13-40DS-1.25C connector)</p> <p>1 x 1 x 5 pin, pitch 2.00mm Wafer connector for LCD inverter backlight connector (5V/12V)</p> <p>1 x 1 x 3 pin, pitch 2.54mm connector LCD backlight brightness adjustment (PWM/DC)</p> <p>1 x 2 x 5 pin, pitch 2.54mm connector for front Audio</p> <p>1 x 3 pin, pitch 2.54mm connector for S/PDIF</p> <p>1 x 4 pin, pitch wafer 2.00mm connector for 3W x 2 Speaker</p> <p>1 x 2 x 5 pin, pitch 2.00mm connector for Keyboard &amp; Mouse</p> <p>1 x 4 pin, pitch 2.00mm connector for CIR</p> <p>1 x 3 pin, pitch 2.00mm connector for CMOS clear</p> <p>1 x 1 x 4 pin, pitch 2.54mm CPU fan connector with smart fan function supported</p> <p>2 x 1 x 4 pin, pitch 2.00mm connector for LAN Activity Indicator LED</p> <p>1 x 2 x 2 pin, pitch 4.20mm connector for power input connector</p> <p>1 x 1 x 3 pin, pitch 2.54mm connector for AT/ATX mode Fanless Operating</p>
<b>Rear I/O Connectors</b>	
<b>Rear Side External I/O Connector</b>	<p>2 x RJ-45</p> <p>1 x VGA</p> <p>1 x HDMI</p> <p>1 x Mic-In and 1 x Line-out</p> <p>1 x DC Jack lockable connector type</p>


<b>Mechanical &amp; Environmental</b>	
<b>Power Requirement</b>	DC in +12V
<b>ACPI</b>	Single power ATX Support S0, S3, S4, S5 ACPI 3.0 Compliant
<b>Power on Type</b>	AT / ATX mode Switchable Through Jumper
<b>Operating Temp.</b>	0 ~ 60°C (32~140°F)
<b>Storage Temp.</b>	-40 ~ +75°C
<b>Operating Humidity</b>	0%~90% relative humidity, non-condensing
<b>Size (L x W)</b>	6.7" x 6.7" (170mm x 170mm)
<b>Weight</b>	0.40 kg

**Note:**

1. If user want to install Win 8.1 Pro OS on eMMC of EMX-BSWP motherboard, User must do:
  - A. BIOS setup menu must select eMMC mode with "PCI mode"(because selection with "ACPI mode" during OS install, OS cannot find eMMC to install).
  - B. Windows OS must use Microsoft Win 8.1 Pro with update version of OS image to install.
2. Brightness control method choose "OS driver", due to Win7 VGA Driver will cause brightness at 100%, Backlight adjustment only support to maximum voltage to **2.5V**. Therefore, should change item value string as Image 1, when choose Brightness control method "OS driver", please use OS Win8/10.
3. Win7 does not support SD card.
4. When OS is Win7/DOS(default), please choose "Legacy System/Win7" at BIOS setup item. When OS is Win8/10, please choose "Win8/Win10" at BIOS setup item (Please refer page.65 BOM Config settings.)
5. Specifications are subject to change without notice.

## 1.6 Architecture Overview—Block Diagram

The following block diagram shows the architecture and main components of EMX-BSWP.




## 2. Hardware Configuration

**Note:****SD Card**

3.3V SD Card AF% less than 5%. UHS-I cards operating at 1.8V are not affected.

Usage of SD cards operating at 3.3V should be minimized and usage should be limited to UHS-I type SD cards operating at 1.8V. Inserting the 3.3V SD card, and leaving it in the system, as extended storage, reduces the life of the interface. Occasional usage of 3.3V SD card, inserting the card –transferring data to or from the 3.3V SD card–then removing the 3.3V SD card, is not a concern. Customers have the option to enable a default D3 device setting to extend the life of the 3.3V SD card interface, if supported by the OS.


## 2.1 Product Overview



## 2.2 Jumper and Connector List

You can configure your board to match the needs of your application by setting jumpers. A jumper is the simplest kind of electric switch.

It consists of two metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To “close” a jumper you connect the pins with the clip. To “open” a jumper you remove the clip. Sometimes a jumper will have three pins, labeled 1, 2, and 3. In this case, you would connect either two pins.



The jumper settings are schematically depicted in this manual as follows:



A pair of needle-nose pliers may be helpful when working with jumpers.

Connectors on the board are linked to external devices such as hard disk drives, a keyboard, or floppy drives. In addition, the board has a number of jumpers that allow you to configure your system to suit your application.

If you have any doubts about the best hardware configuration for your application, contact your local distributor or sales representative before you make any changes.

The following tables list the function of each of the board's jumpers and connectors.

### Jumpers

Label	Function	Note
JRI1/2/3/4/5/6	Serial port 1/2/3/4/5/6 pin9 signal select	3 x 2 header, pitch 2.00mm
JMSW1	SATA2/MSATA1 mPCIe slot selector	6 x 2 header, pitch 2.00mm
JSBKL1	LVDS Back Light power selection	3 x 1 header, pitch 2.54mm
JSATX1	AT/ATX Power Mode Select	3 x 1 header, pitch 2.54mm
CMOS1	Clear CMOS	3 x 1 header, pitch 2.00mm

### Connectors


Label	Function	Note
FAN1	CPU fan connector	4 x 1 wafer, pitch 2.54mm
FPT1	Miscellaneous setting connector 1	5 x 2 header, pitch 2.54 mm
FPT2	Miscellaneous setting connector 2	5 x 2 header, pitch 2.54 mm
DIMM1/2	204-pin DDR3L DIMM socket	

**EMX-BSWP User's Manual**


<b>FAUD1</b>	Front Audio connector	5 x 2 header, pitch 2.54 mm
<b>JBKL1</b>	LCD Inverter connector	5 x 1 wafer, pitch 2.00mm
<b>SPI1</b>	SPI connector	4 x 2 header, pitch 2.00mm
<b>COM1</b>	Serial Port 1 connector	5 x 2 header, pitch 2.00mm
<b>COM2</b>	Serial Port 2 connector	5 x 2 header, pitch 2.00mm
<b>COM3</b>	Serial Port 3 connector	5 x 2 header, pitch 2.00mm
<b>COM4</b>	Serial Port 4 connector	5 x 2 header, pitch 2.00mm
<b>COM5</b>	Serial Port 5 connector	5 x 2 header, pitch 2.00mm
<b>COM6</b>	Serial Port 6 connector	5 x 2 header, pitch 2.00mm
<b>DIO1</b>	General purpose I/O connector	6 x 2 header, pitch 2.00mm
<b>SPK1</b>	Speaker connector	1 x 4 wafer, pitch 2.00 mm
<b>LVDS1</b>	LVDS Connector	DIN 40-pin wafer, pitch 1.25mm
<b>USB1/2</b>	USB connector 1/2	
<b>USB3/4</b>	USB connector 3/4	5 x 2 header, pitch 2.54mm
<b>SPDIF1</b>	Sony/Philips Digital Interface	3 x 1 header, pitch 2.54 mm
<b>LAN1/2</b>	RJ-45 Ethernet 1/2	
<b>PCIE1</b>	PCIe connector	
<b>LED1</b>	LED indicator connector 1	4 x 1 header, pitch 2.00mm
<b>LED2</b>	LED indicator connector 2	4 x 1 header, pitch 2.00mm
<b>KBMS1</b>	PS/2 keyboard & mouse connector	5 x 2 header, pitch 2.00 mm
<b>BT1</b>	Battery connector	2 x 1 wafer, pitch 1.25mm
<b>MSATA1</b>	Full size mPCIe Slot	
<b>MPCIE1</b>	Mini-PCIe connector 1	
<b>JRS485</b>	Serial Port 1 RS485/422 Mode connector	3 x 2 header, pitch 2.00 mm
<b>JLPC1</b>	LPC connector	5 x 2 header, pitch 2.00mm
<b>PWR1</b>	Power connector	2 x 2 wafer, pitch 4.20mm
<b>SATA1/2</b>	Serial ATA connector 1/2	
<b>SPWR1/2</b>	SATA Power connector 1/2	4 x 1 wafer, pitch 2.54mm
<b>EC1</b>	EC_Program	5 x 2 header, pitch 2.00 mm
<b>DCIN1</b>	DC Power-in connector	
<b>SIM1</b>	SIM card slot	
<b>HDMI1</b>	HDMI connector	
<b>LOUT1</b>	Line-out audio jack	
<b>MIC1</b>	Mic-in audio jack	
<b>VGA1</b>	VGA connector	

2.3 Setting Jumpers & Connectors


2.3.1 Serial port 1/2/3/4/5/6 pin9 signal select (JR11/JR12/JR13/JR14/JR15/JR16)




Ring\*



+5V




+12V




\* Default

2.3.2 SATA2/MSATA1 mPCIe slot selector (JMSW1)




SATA2 Connector \*

(SATA2 Connector enabled, MSATA1 slot Disabled)



MSATA1 mPCIe slot

(MSATA1 slot enabled, SATA2 Connector Disabled)




\* Default


Note:

SATA2/MSATA1 shared SATA signal, can not be used simultaneously.


2.3.3 LVDS Back Light power selection (JSBKL1)



PWM Mode\*(Max current: 2A)




DC Mode(Max current: 2A)




\* Default


2.3.4 AT/ATX Power Mode Select (JSATX1)



ATX\*






AT





\* Default

2.3.5 Clear CMOS (CMOS1)





\* Default

2.3.6 LCD Inverter connector (JBKL1)





PIN	Signal	Max current
1	+12V	2A
2	GND	
3	LVDS_BKLTEN	
4	LVDS_BKLADJ	
5	+5V	2A

2.3.7 Serial port 1/2 connector (COM1/2)





Signal	PIN	PIN	Signal
DCD	1	2	RXD
TXD	3	4	DTR
GND	5	6	DSR
RTS	7	8	CTS
RI	9	10	NC

2.3.8 Serial port 3/4/5/6 connector (COM3/4/5/6)





Signal	PIN	PIN	Signal
NC	10	9	RI
CTS	8	7	RTS
DSR	6	5	GND
DTR	4	3	TXD
RXD	2	1	DCD

2.3.9 Serial Port 1 RS485/422 Mode connector (JRS485)





Signal	PIN	PIN	Signal
GND	6	5	+5V
422RX+	4	3	485TX+
422RX-	2	1	485TX-

2.3.10 General purpose I/O connector (DIO1)





Signal	PIN	PIN	Signal
+5V	12	11	GND
SMB_DATA	10	9	SMB_CLK
DO3	8	7	DI3
DO2	6	5	DI2
DO1	4	3	DI1
DO0	2	1	DI0

2.3.11 SATA Power connector 1/2 (SPWR1/2)





PIN	Signal	Max current
1	+V5S_SATA	3A
2	GND	
3	GND	
4	+V12S_SATA	3A

2.3.12 Power connector (PWR1)





Signal	PIN	PIN	Signal
GND	1	2	GND
+VIN_12V	3	4	+VIN_12V

2.3.13 USB connector 3/4 (USB3/4)





Signal	PIN	PIN	Signal
+V5A_USB01	1	2	+V5A_USB01
USB_DN0	3	4	USB_DN1
USB_DP0	5	6	USB_DP1
GND	7	8	GND
		10	NC

2.3.14 Battery connector (BT1)





Signal	PIN
+3V	1
GND	2

2.3.15 LVDS connector (LVDS1)



Signal	PIN	PIN	Signal
+5V	2	1	+3.3V
+5V	4	3	+3.3V
EDP_DDC_DAT	6	5	EDP_DDC_SCL
GND	8	7	GND
LVDS_DATAP0	10	9	LVDS_DATAP1
LVDS_DATAN0	12	11	LVDS_DATAN1
GND	14	13	GND
LVDS_DATAP2	16	15	LVDS_DATAP3
LVDS_DATAN2	18	17	LVDS_DATAN3
GND	20	19	GND
LVDS_DATAP4	22	21	LVDS_DATAP5
LVDS_DATAN4	24	23	LVDS_DATAN5
GND	26	25	GND
LVDS_DATAP6	28	27	LVDS_DATAP7
LVDS_DATAN6	30	29	LVDS_DATAN7
GND	32	31	GND
LVDS_CLK1P	34	33	LVDS_CLK2P
LVDS_CLK1N	36	35	LVDS_CLK2N
GND	38	37	GND
+12V	40	39	+12V

2.3.16 Audio connector (FAUD1)





Signal	PIN	PIN	Signal
LINE2_JD	10	9	LINE2_L
		7	SENSE_B
MIC2_JD	6	5	LINE2_R
AUD_FRONT_DET	4	3	MIC2_R
GND	2	1	MIC2_L

2.3.16.1 Signal Description –Front Audio connector (FAUD1)



Signal	Signal Description
LINE2_JD	AUDIO IN (LINE_RIN/LIN)sense pin
MIC2_JD	MIC IN (MIC_RIN/LIN) sense pin

2.3.17 LPC connector (JLPC1)





Signal	PIN	PIN	Signal
GND	10	9	LPC_SERIRQ
LPC_DEG_CLK	8	7	LPC_AD3
LPC_FRAME#	6	5	LPC_AD2
PLT_RST#	4	3	LPC_AD1
+3.3V	2	1	LPC_AD0

2.3.18 EC\_Program (EC1)





Signal	PIN	PIN	Signal
EC_SMDATA_DBG	10	9	EC_SMCLK_DBG
NC	8	7	EC_HOLD#
EC_FSMOSI	6	5	EC_FSMIOSO
EC_FSCK	4	3	EC_FSCE#
GND	2	1	+3.3A_ECSPi

2.3.19 PS/2 keyboard & mouse connector (KBMS1)





Signal	PIN	PIN	Signal
NC	10	9	NC
NC	8	7	NC
MSCK	6	5	MSDAT
+5VSB	4	3	GND
KBCK	2	1	KBDAT

2.3.20 SPI connector (SPI1)




Signal	PIN	PIN	Signal
+VSPI_BIOS	1	2	GND
SPI_CS0#	3	4	SPI_CLK
SPI_MISO	5	6	SPI_MOSI
SPI_HOLD#	7		

2.3.21 Sony/Philips Digital Interface (SPDIF1)





Signal	PIN
GND	3
SPDIF_OUT	2
+5V	1

2.3.22 Speaker connector (SPK1)





Signal	PIN
RSPK-	4
RSPK+	3
LSPK-	2
LSPK+	1

2.3.23 Miscellaneous setting connector 1 (FPT1)



Signal	PIN	PIN	Signal
+HD_LED	1	2	+PWR_LED
-HD_LED	3	4	-PWE_LED
+Reset	5	6	+PWR_BNT
-Reset	7	8	-PWR_BNT
NC	9		

2.3.24 Miscellaneous setting connector 2 (FPT2)




Signal	PIN	PIN	Signal
Speaker+	1	2	BLK_VR(10K)
NC	3	4	BLK_UP
NC	5	6	BLK_DN
Speaker-	7	8	GND
NC	9	10	

Note:


- 1. Pin2 with GND: Control LVDS Backlight by use Variable Resistor.
- 2. BLK\_UP with GND/BLK\_DN with GND: Step control LVDS Backlight by use button and BIOS must to be set “BR Button”. (Please refer to page.88)

2.3.25 LED indicator connector 1 (LED1)





Signal	PIN
L1_1000#_LED	4
L1_100#_LED	3
L1_ACT_N	2
L1_ACT_P	1

2.3.26 LED indicator connector 2 (LED2)



Signal	PIN
L2_1000#_LED	4
L2_100#_LED	3
L2_ACT_N	2
L2_ACT_P	1

2.3.27 CPU fan connector (FAN1)



Signal	PIN
GND	1
+12V	2
CPU_FANIN	3
CPU_FANOUT	4

## 3.BIOS Setup

---

### 3.1 Introduction

The BIOS setup program allows users to modify the basic system configuration. In this following chapter will describe how to access the BIOS setup program and the configuration options that may be changed.

### 3.2 Starting Setup

The AMI BIOS™ is immediately activated when you first power on the computer. The BIOS reads the system information contained in the NVRAM and begins the process of checking out the system and configuring it. When it finishes, the BIOS will seek an operating system on one of the disks and then launch and turn control over to the operating system.

While the BIOS is in control, the Setup program can be activated in one of two ways:

By pressing <Del> or <F2> immediately after switching the system on, or

By pressing the <Del> or <F2> key when the following message appears briefly at the left-top of the screen during the POST (Power On Self Test).

**Press <Del> or <F2> to enter SETUP**

If the message disappears before you respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the "RESET" button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys. If you do not press the keys at the correct time and the system does not boot, an error message will be displayed and you will again be asked to.

**Press F1 to Continue, DEL to enter SETUP**

### 3.3 Using Setup

In general, you use the arrow keys to highlight items, press <Enter> to select, use the PageUp and PageDown keys to change entries, press <F1> for help and press <Esc> to quit. The following table provides more detail about how to navigate in the Setup program using the keyboard.

Button	Description
↑	Move to previous item
↓	Move to next item
←	Move to the item in the left hand
→	Move to the item in the right hand
Esc key	Main Menu -- Quit and not save changes into NVRAM Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu
+ key	Increase the numeric value or make changes
- key	Decrease the numeric value or make changes
F1 key	General help, only for Status Page Setup Menu and Option Page Setup Menu
F2 key	Previous Values.
F3 key	Optimized defaults
F4 key	Save & Exit Setup

- **Navigating Through The Menu Bar**

Use the left and right arrow keys to choose the menu you want to be in.



**Note:** Some of the navigation keys differ from one screen to another.

- **To Display a Sub Menu**

Use the arrow keys to move the cursor to the sub menu you want. Then press <Enter>. A “➤” pointer marks all sub menus.

### 3.4 Getting Help

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc> or the F1 key again.

### 3.5 In Case of Problems

If, after making and saving system changes with Setup, you discover that your computer no longer is able to boot, the AMI BIOS supports an override to the NVRAM settings which resets your system to its defaults.

The best advice is to only alter settings which you thoroughly understand. To this end, we strongly recommend that you avoid making any changes to the chipset defaults. These defaults have been carefully chosen by both BIOS Vendor and your systems manufacturer to provide the absolute maximum performance and reliability. Even a seemingly small change to the chipset setup has the potential for causing you to use the override.

## 3.6 BIOS setup

Once you enter the Aptio Setup Utility, the Main Menu will appear on the screen. The Main Menu allows you to select from several setup functions and exit choices. Use the arrow keys to select among the items and press <Enter> to accept and enter the sub-menu.

### 3.6.1 Main Menu

This section allows you to record some basic hardware configurations in your computer and set the system clock.



### 3.6.1.1 System Language

This option allows choosing the system default language.

### 3.6.1.2 System Date

Use the system date option to set the system date. Manually enter the day, month and year.

### 3.6.1.3 System Time

Use the system time option to set the system time. Manually enter the hours, minutes and seconds.




**Note:** The BIOS setup screens shown in this chapter are for reference purposes only, and may not exactly match what you see on your screen.



Visit the Avalue website ([www.avalue.com.tw](http://www.avalue.com.tw)) to download the latest product and BIOS information.

## 3.6.2 Advanced Menu



This section allows you to configure your CPU and other system devices for basic operation through the following sub-menus.







3.6.2.1 Driver Health





3.6.2.2 Trusted Computing















Item	Options	Description
Security Device Support	Disable, Enable[Default]	Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1Ainterface will not be available.
TPM State	Disabled, Enabled[Default]	Enable/Disable Security Device. NOTE: Your Computer will reboot during restart in order to

		change State of the Device.
<b>Pending operation</b>	None <b>[Default]</b> TPM Clear	Schedule an Operation for the Security Device. NOTE: Your Computer will reboot during restart in order to change State of Security Device.
<b>Platform Hierarchy</b>	Disabled, Enabled <b>[Default]</b>	Enable or Disable Platform Hierarchy.
<b>Endorsement Hierarchy</b>	Disabled, Enabled <b>[Default]</b>	Enable or Disable Endorsement Hierarchy.
<b>HashPolicy</b>	Sha-1 <b>[Default]</b> Sha-2	Select the Hash policy to use. SHA-2 is most secure but might not be supported by all Operating Systems.


### 3.6.2.3 APCI Settings









## EMX-BSWP User's Manual



Item	Options	Description
<b>Enable ACPI Auto Configuration</b>	Disabled[Default], Enabled	Enables or Disables BIOS ACPI Auto Configuration.
<b>Enable Hibernation</b>	Disabled Enabled[Default],	Enables or Disables System ability to Hibernate (OS/S4 Sleep State). This option may be not effective with some OS.
<b>ACPI Sleep State</b>	Suspend Disabled, S3 (Suspend to RAM)[Default]	Select the highest ACPI sleep state the system will enter when the SUSPEDN button is pressed.
<b>ErP Function</b>	Disabled[Default], Enabled	ErP Function (Deep S5).
<b>PWR-On After PWR-Fail</b>	Off[Default] On Last state	AC loss resume.
<b>Watch Dog</b>	Disabled[Default], 30 sec 40 sec 50 sec 1 min 2 min 10 min 30 min	Select WatchDog.

3.6.2.4 IT8528 Super IO Configuration

You can use this item to set up or change the IT8528 Super IO configuration for serial ports. Please refer to 3.6.2.4.1~ 3.6.2.4.6 for more information.





Item	Options	Description
Serial Port 1 Configuration	Set Parameters of Serial Port 1 (COMA).	
COM2/CIR Selection	CIR COM2[Default],	Switch to select UART-B/CIR.

## EMX-BSWP User's Manual


<b>Serial Port 2 Configuration</b>	Set Parameters of Serial Port 2 (COMB).
<b>Serial Port 3 Configuration</b>	Set Parameters of Serial Port 3 (COMC).
<b>Serial Port 4 Configuration</b>	Set Parameters of Serial Port 4 (COMD).
<b>Serial Port 5 Configuration</b>	Set Parameters of Serial Port 5 (COME).
<b>Serial Port 6 Configuration</b>	Set Parameters of Serial Port 6 (COMF).

### 3.6.2.4.1 Serial Port 1 Configuration




Item	Option	Description
Serial Port	Enabled[Default], Disabled	Enable or Disable Serial Port (COM).
Change Settings	Auto[Default] IO=3F8h; IRQ=4; IO=3F8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2F8h; IRQ=3,4,5,6,7,9,10,11,12; IO=3E8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,9,10,11,12;	Select an optimal setting for Super IO Device.
UART 232 422 485	UART 232[Default], UART 422, UART 485	Change the Serial Port as RS232/ 422/ 485

### 3.6.2.4.2 Serial Port 2 Configuration




Item	Option	Description
Serial Port	Enabled[Default], Disabled	Enable or Disable Serial Port (COM).
Change Settings	Auto[Default] IO=2F8h; IRQ=3; IO=3F8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2F8h; IRQ=3,4,5,6,7,9,10,11,12; IO=3E8h; IRQ=3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,9,10,11,12;	Select an optimal setting for super IO Device.

3.6.2.4.3 Serial Port 3 Configuration




Item	Option	Description
Serial Port	Enabled[Default], Disabled	Enable or Disable Serial Port (COM).
Change Settings	Auto[Default] IO=3E8h; IRQ=5; IO=3E8h; IRQ=3,4,5,6,7,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,10,11,12; IO=200h; IRQ=3,4,5,6,7,10,11,12; IO=208h; IRQ=3,4,5,6,7,10,11,12;	Select an optimal setting for super IO Device.

3.6.2.4.4 Serial Port 4 Configuration



Item	Option	Description
Serial Port	Enabled[Default], Disabled	Enable or Disable Serial Port (COM).
Change Settings	Auto[Default] IO=2E8h; IRQ=5; IO=3E8h; IRQ=3,4,5,6,7,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,10,11,12; IO=200h; IRQ=3,4,5,6,7,10,11,12; IO=208h; IRQ=3,4,5,6,7,10,11,12;	Select an optimal setting for super IO Device.

3.6.2.4.5 Serial Port 5 Configuration





Item	Option	Description
Serial Port	Enabled[Default], Disabled	Enable or Disable Serial Port (COM).
Change Settings	Auto[Default] IO=200h; IRQ=5; IO=3E8h; IRQ=3,4,5,6,7,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,10,11,12; IO=200h; IRQ=3,4,5,6,7,10,11,12; IO=208h; IRQ=3,4,5,6,7,10,11,12;	Select an optimal setting for super IO Device.

## 3.6.2.4.6 Serial Port 6 Configuration





Item	Option	Description
Serial Port	Enabled[Default], Disabled	Enable or Disable Serial Port (COM).
Change Settings	Auto[Default] IO=208h; IRQ=5; IO=3E8h; IRQ=3,4,5,6,7,10,11,12; IO=2E8h; IRQ=3,4,5,6,7,10,11,12; IO=200h; IRQ=3,4,5,6,7,10,11,12; IO=208h; IRQ=3,4,5,6,7,10,11,12;	Select an optimal setting for super IO Device.

3.6.2.5 H/W Monitor





Item	Options	Description
Smart Fan Function	Enabled, Disabled[Default]	Enable or Disable Smart Fan.

3.6.2.6 S5 RTC Wake Settings



Item	Options	Description
Wake system from S5	Disabled[Default], Fixed Time Dynamic Time	Enable or disable System wake on alarm event. Select Fixed Time, system will wake on the hr::min::sec specified. Select Dynamic Time, System will wake on the current time + Increase minute(s).



3.6.2.7 Serial Port Console Redirection




Item	Options	Description
Console Redirection	Disabled[Default], Enabled	Console Redirection Enable or Disable.



3.6.2.8 CPU Configuration

Use the CPU configuration menu to view detailed CPU specification and configure the CPU.






## EMX-BSWP User's Manual




Item	Options	Description
Max Freq Ratio	0-255	Max Freq Ratio.
Intel Virtualization Technology	Disabled, Enabled[Default]	When enabled, a VMM can utilize the additional hardware capabilities provided by Virtualization Technology.
Power Technology	Disabled, Energy Efficient Custom[Default]	Enable the power management features.



<b>EIST</b>	Disabled, Enabled[ <b>Default</b> ]	Enable/Disable Intel SpeedStep.
<b>Turbo Mode</b>	Disabled, Enabled[ <b>Default</b> ]	Turbo Mode.
<b>P-STATE Coordination</b>	HW_ALL[ <b>Default</b> ] SW_ALL SW_ANY	Change P-STATE Coordination type.
<b>Package C State limit</b>	C1[ <b>Default</b> ]/3/6/7	Package C State limit.

### 3.6.2.8.1 Socket 0 CPU Information





3.6.2.9 SATA Configuration







## EMX-BSWP User's Manual



Item	Options	Description
<b>SATA Controller</b>	Disabled, Enabled[Default]	Enable/Disable SATA Device.
<b>SATA Mode Selection</b>	AHCI[Default]	Determines how SATA controller operate.
<b>SATA Interface Speed</b>	Gen1 Gen2 Gen3[Default]	Select SATA Interface Speed, CHV A1 always with Gen 1 Speed.



Port0/1	Disabled, Enabled[Default]	Enable/Disable SATA Port.
---------	-------------------------------	---------------------------



### 3.6.2.10 Miscellaneous Configuration





Item	Options	Description
BOM Config	Win8 Legacy System (WIN 7)[Default] Yocto Linux	Select OS type to install.

3.6.2.11 LPSS & SCC Configuration








Item	Options	Description
SCC eMMC Support (D16:F0)	ACPI Mode PCI Mode Disabled[Default]	SCC eMMC power management function support selection.
eMMC Secure Erase	Enabled Disabled[Default]	Disable/Enable eMMC Secure Erase. When enabled, all the data on eMMC will

		be erased.
<b>SCC SDIO Support (D17:F0)</b>	ACPI Mode PCI Mode[ <b>Default</b> ] Disabled	SCC SDIO Support Enable/Disable.
<b>SCC SD Card Support (D18:F0)</b>	ACPI Mode PCI Mode[ <b>Default</b> ] Disabled	SCC SD Card Support Enable/Disable.
<b>eMMC Driver Operating Mode</b>	Basic Frequency Up to 26MHz Up to 52MHz Auto Detect[ <b>Default</b> ]	Select the operating frequency in eMMC driver.

### 3.6.2.12 Network Stack Configuration





EMX-BSWP User’s Manual







Item	Options	Description
Network Stack	Enabled Disabled[Default]	Enable/Disable UEFI Network Stack.

3.6.2.13 CSM Configuration












## EMX-BSWP User's Manual



Item	Options	Description
<b>CSM Support</b>	Enabled[ <b>Default</b> ] Disabled,	Enable/Disable CSM Support.
<b>Option ROM Messages</b>	Force BIOS Keep Current[ <b>Default</b> ]	Set display mode for Option ROM.
<b>Boot option filter</b>	UEFI and Legacy Legacy only UEFI only[ <b>Default</b> ]	This option controls Legacy/UEFI ROMs priority.
<b>Network</b>	Do not launch[ <b>Default</b> ] UEFI Legacy	Controls the execution of UEFI and Legacy PXE OpROM.
<b>Storage</b>	Do not launch UEFI Legacy[ <b>Default</b> ]	Controls the execution of UEFI and Legacy Storage OpROM.
<b>Video</b>	Do not launch UEFI Legacy[ <b>Default</b> ]	Controls the execution of UEFI and Legacy Video OpROM.
<b>Other PCI devices</b>	Do not launch UEFI[ <b>Default</b> ] Legacy	Determines OpROM execution policy for devices other than Network, Storage, or Video.



3.6.2.14 SDIO Configuration







Item	Options	Description
SDIO Access Mode	Auto[Default] ADMA SDMA PIO	Auto Option: Access SD device in DMA mode if controller supports it , otherwise in PIO mode. DMA Option: Access SD device in DMA mode. PIO Option: Access SD device in PIO mode.



3.6.2.15 USB Configuration

The USB Configuration menu helps read USB information and configures USB settings.











Item	Options	Description
<b>Legacy USB Support</b>	Enabled[Default] Disabled Auto	Enables Legacy USB support. AUTO option disables legacy support if no USB devices are connected. DISABLE option will keep USB devices available only for EFI applications.
<b>XHCI Hand-off</b>	Enabled Disabled[Default]	This is a workaround for OS without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.
<b>USB Mass Storage Driver Support</b>	Enabled[Default]	Enable/Disable USB Mass Storage Driver

## EMX-BSWP User's Manual

	Disabled	Support.
<b>USB transfer time-out</b>	1 sec 5 sec 10 sec 20 sec <b>[Default]</b>	The time-out value for Control, Bulk, and Interrupt transfers.
<b>Device reset time-out</b>	10 sec 20 sec <b>[Default]</b> 30 sec 40 sec	USB mass storage device Start Unit command time-out.
<b>Device power-up delay</b>	Auto <b>[Default]</b> Manual	Maximum time the device will take before it properly reports itself to the Host Controller. 'Auto' uses default value: for a Root port it is 100ms, for a Hub port the delay is taken form Hub descriptor.
<b>Generic-SD/MMC 1.00</b>	Auto <b>[Default]</b> Floppy Forced FDD Hard Disk CD-ROM	Mass storage device emulation type. 'AUTO' enumerates devices according to their media format. Optical drives are emulated as 'CDROM', drives with no media will be emulated according to a drive type.


### 3.6.2.16 IntelRMT Configuration







Item	Options	Description
Intel RMT Support	Disabled <b>[Default]</b> Enabled,	Intel RMT(Ready Mode Technology) SSDT table will be loaded if enabled.

3.6.3 Chipset







3.6.3.1 North Bridge



Item	Option	Description
Max TOLUD	2 GB 3 GB[Default]	Maximum Value of TOLUD.



3.6.3.1.1 Intel IGD Configuration









Item	Option	Description
VGA Enabled/Disabled Setting	Enabled[Default], Disabled	Enable GOP Driver will unload VBIOS; Disable it will load VBIOS.
Primary Display	IGD PCIe Auto[Default]	Select which of IGD/PCI Graphics device should be Primary Display.
GFX Boost	Enabled, Disabled[Default]	Enable/Disable GFX Boost.

3.6.3.1.2 IGD - LCD Control








Item	Option	Description
Active LVDS (Ch7511)	Enabled[Default] Disabled	Active Internal LVDS(eDP->Ch7511-to -LVDS).
CH7511 EDID Panel Option	1024x768 24/1[Default] 800x600 18/1 1024x768 18/1	Port1-EDP to LVDS (Chrontel 7511) Panel EDID Option.


## EMX-BSWP User's Manual



	1366x768 18/1 1024x600 18/1 1280x800 18/1 1920x1200 24/2 640x480 18/1 800x480 18/1 1920x1080 18/2 1280x1024 24/2 1440x900 18/2 1600x1200 24/2 1366x768 24/1 1920x1080 24/2 1680x1050 24/2	
<b>Brightness Control Method</b>	<b>BIOS[Default]</b> BR Button OS driver	LVDS Brightness Control Method. 1.BIOS 2.Brightness Button 3.Variable Resistor. Note: BR Button: Must be use FPT-2 Pin4 and Pin6.
<b>LVDS Back Light PWM</b>	00% 25% 50% 75% 100% <b>[Default]</b>	Select LVDS back light PWM duty.
<b>LVDS Back Light PWM Frequency</b>	200 <b>[Default]</b> 300 400 500 700 1k 2k 3k 5k 10k 20k	Select LVDS back light PWM Frequency.


3.6.3.2 South Bridge



3.6.3.2.1 Azalia Configuration










Item	Option	Description
<b>Audio Controller</b>	Enabled[Default], Disabled	Control Detection of the Azalia device. Disabled = Azalia will be unconditionally disabled. Enabled = Azalia will be unconditionally Enabled.
<b>Azalia HDMI Codec Port B</b>	Enabled[Default], Disabled	Enable/Disable HDMI Port codec for Azalia.
<b>AUD Gain Setting</b>	11db 14db 19db[Default] 25db	Select db Value of the AUD Gain.


### 3.6.3.2.2 USB Configuration








Item	Option	Description
XHCI Mode	Enabled[Default], Disabled	Mode of operation of xHCI controller.
USB Standby Power Setting	Enabled[Default], Disabled	Enabled/Disabled USB Standby Power.



3.6.3.2.3 PCI Express Configuration





3.6.3.2.3.1 PCIe Express Root Port1









Item	Option	Description
PCI Express Root Port 1/2/3/4	Enabled[Default], Disabled	Control the PCI Express Root Port.
ASPM	Disabled[Default] L0s L1 L0sL1 Auto	PCI Express Active State Power Management settings.

<b>PCIe Speed</b>	Auto[Default] Gen 2 Gen 1	Configure PCIe Speed. CHV A1 always with Gen 1 Speed.
-------------------	---------------------------------	---

### 3.6.4 Security





- **Administrator Password**

Set setup Administrator Password

- **User Password**

Set User Password


3.6.4.1 Secure Boot menu



Item	Option	Description
Secure Boot	Disabled[Default] Enabled	Secure Boot can be enabled if 1.System running in User mode with enrolled Platform Key(PK) 2.CSM function is disabled.



<b>Secure Boot Mode</b>	Standard Custom <b>[Default]</b>	Secure Boot mode selector. 'Custom' Mode enables users to change Image Execution policy and manage Secure Boot Keys.
-------------------------	-------------------------------------	--



### 3.6.4.1.1 Key Management






Item	Option	Description
<b>Provision Factory Default Keys</b>	Enabled, Disabled <b>[Default]</b>	Install Factory default Secure Boot Keys when System is in Setup Mode.

3.6.5 Boot











Item	Option	Description
<b>Setup Prompt Timeout</b>	1~ 65535	Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.
<b>Bootup NumLock State</b>	On[Default] Off	Select the Keyboard NumLock state
<b>Quiet Boot</b>	Disabled[Default] Enabled	Enables or disables Quiet Boot option
<b>Fast Boot</b>	Disabled[Default] Enabled	Enables or disables boot with initialization of a minimal set of devices required to launch active boot option. Has no effect for BBS boot options.
<b>New Boot Option Policy</b>	Default[Default] Place First Place Last	Controls the placement of newly detected UEFI boot options.
<b>Boot Option #1/2</b>	Set the system boot order.	

3.6.6 Save and exit



Item	Option	Description
Expert mode	DQV mode[Default] Expert mode	Switch Expert mode or DQV mode.
Save Changes and Reset	Reset the system after saving the changes.	
Discard Changes and Reset	Any changes made to BIOS settings during this session of the BIOS setup program are discarded. The setup program then exits and	

	reboots the controller.
<b>Restore Defaults</b>	This option restores all BIOS settings to the factory default. This option is useful if the controller exhibits unpredictable behavior due to an incorrect or inappropriate BIOS setting.
<b>Launch EFI Shell from filesystem device</b>	Attempts to Launch EFI Shell application (Shellx64.efi) from one of the available filesystem devices.

## 4. Drivers Installation




**Note:** Installation procedures and screen shots in this section are for your reference and may not be exactly the same as shown on your screen.

## 4.1 Install Chipset Driver

Insert the Supporting DVD-ROM to DVD-ROM drive, and it should show the index page of Avalue's products automatically. If not, locate Index.htm and choose the product from the menu left.



**Note:** The installation procedures and screen shots in this section are based on Windows 8.1 operation system. If the warning message appears while the installation process, click Continue to go on.



**Step 3. Click Install.**



**Step1. Click Next.**



**Step 4. Click Finish** to complete setup.




**Step 2. Click Accept.**

## 4.2 Install VGA Driver


Insert the Supporting DVD-ROM to DVD-ROM drive, and it should show the index page of Avalue's products automatically. If not, locate Index.htm and choose the product from the menu left.




**Note:** The installation procedures and screen shots in this section are based on Windows 8.1 operation system.




**Step 3. Click Next.**



**Step 1. Click Next** to continue installation.




**Step 4. Click Next.**



**Step 2.**

Click **Yes** to accept license agreement.




**Step 5. Click Finish** to complete setup.

## 4.3 Install USB3.0 Driver


Insert the Supporting CD-ROM to CD-ROM drive, and it should show the index page of Avalue's products automatically. If not, locate Index.htm and choose the product from the menu left.



**Note:** The installation procedures and screen shots in this section are based on Windows 8.1 operation system.




**Step 3. Click Next**



**Step 1. Click Next** to continue setup.



**Step 4. Click Finish** to complete the setup



**Step 2. Click Next.**

### 4.4 Install Serial IO Driver

Insert the Supporting CD-ROM to CD-ROM drive, and it should show the index page of Avalue's products automatically. If not, locate Index.htm and choose the product from the menu left.



**Note:** The installation procedures and screen shots in this section are based on Windows 8.1 operation system.



**Step 1.** Click **Next** to continue setup.



**Step 2.** Click **Finish** to complete the setup.

## 4.5 Install SMSC Hub Driver


Insert the Supporting CD-ROM to CD-ROM drive, and it should show the index page of Avalue's products automatically. If not, locate Index.htm and choose the product from the menu left.



**Note:** The installation procedures and screen shots in this section are based on Windows 8.1 operation system.



**Step 1.** Click **Install** to continue setup.




**Step 2.** Click **Yes** to complete the setup.

### 4.6 Install Audio Driver (For Realtek ALC662 HD Audio)


Insert the Supporting DVD-ROM to DVD-ROM drive, and it should show the index page of Avalue's products automatically. If not, locate Index.htm and choose the product from the menu left.



**Note:** The installation procedures and screen shots in this section are based on Windows 8.1 operation system. If the warning message appears while the installation process, click Continue to go on.



**Step1.** Click **Next** to Install.




**Step 2.** Select **Finish** to complete Installation.

## 4.7 Install LAN Driver (For Intel I211AT)


Insert the Supporting DVD-ROM to DVD-ROM drive, and it should show the index page of Avalue's products automatically. If not, locate Index.htm and choose the product from the menu left.



**Note:** The installation procedures and screen shots in this section are based on Windows 8.1 operation system.



**Step 3. Click Next.**




**Step 1. Click Next** to continue installation.



**Step 4. Click Install.**




**Step 2. Click Next.**



**Step 5. Wait** while installing.


## EMX-BSWP User's Manual



**Step 6.** Click **Finish** to complete setup.

# 5. Mechanical Drawing

---



Unit: mm

